



X2
A29 00
C29 00
A28 00
C28 00
A26 /OE0
C26 /IE1
A17 MP1
C17 MP2
A16 MP3
C16 MP4
A15 MP5
C15 MP6
A14 MP7
C14 MP8
A13 SP
C13 SP
A12 SP
C12 SP
A11 SP
C11 SP
A10 SP
C10 SP

X1
A29 SP
C29 SP
A28 12
C28 12
A27 /BA0
C27 /BA1
A25 /REFRESH
A26 /M1
C26 /RDY
A24 /WAIT
C24 /IORQ
A23 /INT
C23 /IOO
A22 /Q0
C22 /TART
A21 /DO
C21 /DO
A20 /RESET
C20 /BUSRQ

A19 AB0
C19 AB1
A18 AB2
C18 AB3
A17 AB4
C17 AB5
A16 AB6
C16 AB7
A15 AB8
C15 AB9
A14 AB10
C14 AB11
A13 AB12
C13 AB13
A12 AB14
C12 AB15
A11 AB16
C11 AB17
A10 AB18
C10 AB19
A09 AB20
C09 AB21
A08 AB22
C08 AB23
A07 AB24
C07 AB25
A06 AB26
C06 AB27
A05 AB28
C05 AB29
A04 AB30
C04 AB31
A03 AB32
C03 AB33
A02 AB34
C02 AB35
A01 AB36
C01 AB37

Leiterplatte bstu
K3126 Typ 6620
Stromlaufplan
1.62.518620.0/04
083 - 4 - 710 - 057/04





Leiterplatte bstu
 K5125 Typ 082-8320
 Stromlaufplan
 1.62.518620.0/04
 003-4-710-057/04