

Kabel MODEM - ASK-Adapter

V24

EC 1834

Plotter - EC 1834 !

2	5	4	3	6	13	7
3	4	5	2	20	6	7

15-poliger
EC 1834

25-poliger
MODEM


Plotter

BCA520

3. Platte v. l.
unterster Stecker
5-pol. IFSS-Stecker

Drucker SD 1152

Stecker
5-pol. IFSS-Stecker



Drucker / Anschlusskabel

IFSS

BCA520 - 1152